

Frank Burton & Sons

333 West Broad St., Bridgeton, NJ, 08302
(856)-455-1202 (856)-453-1896 (Fax)
www.frankburtons.com

Project Tip

When connecting vinyl tubing to a brass compression fitting, use the method below to get the best seal possible. Slide the **Brass Compression Nut (1)** onto the vinyl tubing. Next, slide a **plastic compression ferrule (2)** onto the vinyl tubing (a brass compression ferrule can dig into the vinyl tubing when tightened, and cause a leak). And last, insert a **brass insert adapter (3)** into the end of the vinyl tubing. This insert adapter prevents the vinyl tubing from collapsing when the Nut is tightened. Slide the Vinyl tubing into the Compression fitting and tighten securely.

